



User Manual

5G PRO INVERTER

KSY:- 1KW- 4.2KW 1MPPT

Single-Phase Grid-tied Solar Inverter

CATALOGUE

1. SYMBOLS ON THE LABEL	3
2. SAFETY AND WARNINGS	4
3. UNPACKING	5
3.1 Scope of Delivery	5
3.2 Product Overview	6
4. INSTALLING	7
4.1 Installation Requirement	7
4.2 Mounting Location	8
4.3 Mounting	9
4.4 Installing the PE cable	10
4.5 Cable Specification	10
5. COMMISSIONING	11
5.1 Safety Instructions	11
5.2 AC Wire Assembly and Connection	11
5.3 DC Wire Assembly and Connection	11
5.4 Residual Current Protection	12
6. COMMUNICATION	
6.1 System monitoring via Datalogger-RS485/Wi-Fi /GPRS (Optional)	13
7. START UP AND OPERATION	14
7.1 Safety Check Before Start Up	14
7.2 Inverter LED Indicators	15
7.3 Trouble Shooting	17
B DISCONNECTING EROM VOLTAGE SOLIBOES	16

1. SYMBOLS ON THE LABEL

<u>^</u>	DANGER, WARNING AND CAUTION		RECYCLABLE AND REUSABLE
A	HIGH VOLTAGE AVOID CONTACT	*	AVOID DAMP AND MOISTURE
	HIGH TEMPERATURE AVOID CONTACT	10	SHIPMENT STACK LIMIT: 10
(€	CE MARKS	X	DO NOT DISPOSE WITH HOUSEHOLD WASTE
A Smins	PROCEED OPERATIONS AFTER 5 MINUTES DISCHARGE	•	BREAKABLE ITEM
11	PLACE UPWARDS	$\bigcap_{\mathbf{i}}$	USER MANUAL IN PACK


2. SAFETY AND WARNINGS

- 1. All persons who are responsible for mounting, installation, commissioning, maintenance, tests, and service of KSOLARE inverter products must be suitably trained and qualified for corresponding operations. They MUST be experienced and have knowledge of operation safety and professional methods. All installation personnel must have knowledge of all applicable safety information, standards, directives, and regulations.
- 2. When designing or constructing a PV system, all components MUST remain in their permitted operating ranges, and their installation requirements MUST always be fulfilled.
- 3. Under exposure to sunlight, the PV array may generate dangerous output in DC voltage. Contacts with the DC wires, conductors and live components in the inverter may result in lethal shocks.
- 4. High voltages in inver ter could cause lethal electrical shocks. Before proceeding any work, including maintenance and/or service, on the inverter, fully disconnect it from all DC input, AC grid and other voltage sources. There MUST be a 5-minute waiting time after the full disconnection.
- 5. The DC input voltage of the PV array MUST never exceed the maximum input voltage of the inverter.
- 6. DO NOT touch parts of the inverter during operation as heat will be induced and these parts will exceed 60°C.

3. UNPACKING

3.1 Scope of Delivery

Please inspect and check for completeness in the scope of delivery. Confirm with purchase order.




1) RS485/Wi-Fi/GPRS (optional)

3.2 Product Overview X:7.08 in

The total size of KSY - 1KW to 4.2KW 1MPPT is 297 (width) x 223 (Height) x 117 (depth) mm.lt has 1 pairs of PV input terminals & 2 communication ports.lt also has a ICD & LED (or just LED, determined by user) for Getting information & setting prameters at field

The detail describtion is shown below:




KSY -1KW - 4.2KW USER MANUAL 5

Mark Num .	Component	Description
1	LCD&LED or LED	Display and setting device at field
2	PV Terminal (s)	Connected with PV Panel
3	COM1: Wi-Fi/RS485/GPRS	Alternative distant communication method
4	AC Terminal	Connected with A C Grid
5	Secondary PE Terminal	For Grounding Protection


4 INSTALLING

41 Installation Requirement

- 1 Please install the inverters in places that can avoid inadvertent contact.
- 2 Installation method, location and surface must be fitting for the inverter's weight and dimensions
- 3. Please install the inverter in an accessible location for operation, future maintenance and service.
- 4. When installing in residential or domestic environment, it is recommended to install and mount the inverter on a solid, concrete wall surface. Mounting the inverter on composite or plaster boards or walls with similar materials would induce noise during its operation and is therefore not recommended.
- 5. DO NOT cover the inverter NOR place any objects on top of the inverter.
- 6. To ensure sufficient room for heat dissipation and maintenance, the dearing space between inverter(s) and other surroundings is indicated below for reference:




7. Avoid direct exposure to sun light and rain and snow layup



KSY-1KW-4.2KW USER MANUAL 7

4.2 Mounting Location

- 1. DO NOT mount the inverter near any inflammable materials
- 2. DO NOT mount the inverter near any explosive materials,




Backwards

- 3. DO NOT mount the inverter on tilting surface over 15" backwards. Please mount the inverter on a vertical wall surface.
- 4. DO NOT mount the inverter on any surfaces tilting forward or to either sides.
- 5. DO NOT mount the inverter on a horizontal surface.
- 6. For easy installation and operation, please mount the inverter on a height that the display could match eye level.
- 7. The bottom side where all commissioning terminals are equipped MUST always point downwards.


3 Mounting

- 1. Use the Heatsink bracket holes as a template and mark the drill holes. Drill 2 holes using a 10mm bit to 70mm depth.
- 2. Fix the Inverter with the screws and expansion bolts packed in mounting accessories
- 4. Check both sides of the heat sink to ensure the inverter is stably attached.



4.4 Installing the PE cable

- 1. Insert the grounding conductor into the suitable terminal lug and crimp the contact.
- 2. Thread the MS13 screw through the terminal lug.
- 3. Tighten it firmly into the housing (screwdriver type: T25, torque: 2.5Nm).



Information on grounding components:

Object	Description
1	Housing
2	M5 terminal lug with protective conductor
3	M5×13 pan head screw

PE Conductor cross - section: 4-6 mm²

4.5 Cable Specification

No.	Item	Туре	Specifications
1	PE Cable	Single-core outdoor copper cable	Conductor cross-section: 4-6mm ²
2	AC Output cable	Outdoor copper cable	Cross-section:2.5-4 mm ² Cable outer diameter: 5.5-12.5 mm
3	DC Intput cable	Standard outdoor PV cable, PV1-F Model recommended	Conductor Cross-section:2.5-6 mm ² Cable outer diameter: 5-8 mm
4	Meter/RS485	Two-core outdoor shieded twisted pair cable	Conductor Cross-section:0.14-1.0 mm ² Cable outer diameter: appox. 6 mm

5. COMMISSIONING

5.1 Safety Instructions

- 1. Measure the frequency and voltage of grid connection and make sure they follow the inverter's grid connection specifications.
- 2. An external circuit breaker on the AC side (or a fuse) at 1.25*AC rated current is strongly recommended.
- 3. Reliability of all earth connections must be tested and valid .
- 4. Before commissioning, disconnect the inverter and the circuit breaker or fuse, and prevent accidental reconnection.

5.2 AC Wire Assembly and Connection

5.2.1 AC Commissioning




5.3 DC Wire Assembly and Connection


- 1. PV modules of the connected strings must be of: the same time, identical alignment and tilting angle.
- 2. Before commissioning and connecting the PV arrays, the DC switch MUST be open.
- 3. Parallel strings must have the sameumber of modules.
- 4. It is mandatory to use the DC connectors within package for the connection of PV
- 5. The polarity of the PV arrays MUST be compatible to the DC connectors of the inverter.
- 6. The DC input voltage AND DC input current of the PV array MUST never exceed the maximum input allowance of the inverter

DC Commissioning

IF the DC port is MC4: Please follow the logics listed below.



IF the DC port is D4: Please follow the logics listed below.



5.4 Residual Current Protection

This product is equipped with residual current protection device internally, in accordance with IEC60364 - 7 - 712. An external residual current protection device is not needed. If the local regulation demands otherwise, it is recommended to install a 30mA Type B residual current protection device.


6. COMMUNICATION

- 6.1 System monitoring via Datalogger -RS485/Wi-Fi/GPRS (Optional)
- 6.1.1 Wi-Fi/GPRS Datalogger Installation
 Unpack the Datalogger from package.
 - 1. Unscrew the cap in COM1 port.
 - 2. Plug the Datalogger in and tighten.

For use r guidance and configuration of



6.1.2 RS485/Smart Meter Connection



KSY-1KW-4.2KW USER MANUAL 13

START UP AND OPERATION

7.1 Safety Check Before Start Up


Please check before switching on any voltage resources connected to the inverter and closing inverter's DC switch:

- Grid Voltage: Check the grid voltage at point of connection at the inverter complies with permitted range of the inverter.
- 2. Mounting of the inverter: Check if the inverter is properly mounted.
- 3. DC Connectors: Check if the DC connectors are installed correctly on terminals.
- 4. AC Connectors and Wire Assembly: Check if wires are assembled correctly on the AC side and if the AC connector is properly and securely installed. Check if the AC connector is firmly plugged into AC terminal.
- 5. Cables: Check if all cables are reliably connected. Check if the connections are effective, while the insulations are undamaged.
- 6. Groundings: Check all groundings using multimeter and if all exposed metal parts of the inverter are properly grounded.
- 7. DC Voltage: Check if the largest open circuit voltage of PV arrays complies with the permitted range.
- 8. DC Polarity: Check if the wires from DC voltage resource are connected to terminals with correct polarity.
- 9. Grounding Resistance: Check if the grounding resistance of PV strings >1MOhm using a multimeter.

The inverter will start to operate when DC input voltage and grid conditions meet the requirements of inverter startup.

7.2 Inverter LED Indicators

When the inverter operates, LED symbols on display have the following meanings:



8. DISCONNECTING FROM VOLTAGE SOURCES

Before proceeding any operations on inverter, please disconnect the inverter from all voltage resources as described in this manual.

Following these steps in described sequence are mandatory.

- 1. Disconnect miniature circuit breaker and prevent from unintentional reconnections.
- 2. Open the DC switch and prevent the switch from closing unintentionally.
- 3. Use clamps to ensure there is no electrical current in DC wires.
- Disconnect all DC connections and resources. Unplug the DC connectors, and DO NOT pull the cables.



- 5. Use multimeter to ensure the voltage on DC terminals of inverter is 0.
- 6. Unscrew and remove the AC connector.





Danger to life due to high voltages.

Inverter capacitors need 5 minutes to be completely de - energized.

When an error occurs, DO NOT remove the cover of the inverter onsite. Improper operations and attempts may induce electric shock.



Poonam petrol pump, KSolare Technology Park, Sr.No. 62, Hissa No.03, Mangdewadi, Pune, Maharashtra 411046

> Service Email: service@ksolare.com Enquiry Email: Sales@ksolare.com

> > Contact: 8530111222

Follow Us On









UIV



Blink
 Communication Device Connected

 OFF
 Communication Device Disconnected

Grid (AC) Side faults

Fault code	Fault	Solution	
Fault 9	No Grid	 Check Ac (grid) Voltage In connector Phase to Neutral voltages 200V - 250V Phase to Phase Voltage 400V - 450V 	
Fault 10	The grid voltage is out of range	1. Check Grid voltages 2. Phase to Neutral voltages 200V – 250V 3. Phase to Phase Voltage 400V – 450V	
Fault 19	The voltage of N-PE is too high	Check Ac side Neutral to Ground voltage less than 15V	
Waiting	-	Check Connection in AC connector Grid voltages in inverter check version & make Online system	

(Panel) DC Side faults

Fault code	Fault	Solution
Fault 5	PV voltage too high	Check DC side voltages For single phase voltage under 500V For Three phase voltage under 1000V
Fault 6	Surface insulation resistance error	1.Check DC side Positive to Ground voltage & Negative to Ground voltage less than 50v
Display Off	-	1.Check string polarity 2. Check DC voltage For single phase 1kw -3.3kw start up voltage 80V - 500V For single phase 4kw -6.2kw start up voltage 100V - 550V For Three phase 3kw -60kw start up voltage 200V - 1000V For Three phase 60kw -110kw start up voltage 250V - 1100V 3. Loose connection in string / loose crimping

Log complaint on https://bit.ly/3eRZba9
Contact 8530111222 / 7888009282 / 7030955507 /01

7.3 Fault Finding

Classifications of Fault Information

Fault Location	Fault Type	Error Message
DC Side Fault	Failures caused by PV side wiring	F5 - PV voltage too high F6-Surface insulation resistance error F7-GFCI exceeds the permissible range
AC Side Fault	Various faults caused by abnormal power grid or AC side wiring	F0 - 10min average voltage over the protection range F9 - No gird F10 - The grid voltage is out of range F11 - The grid frequency exceeds the range F19 - The voltage of N-PE is too high
Inverter Fault	Fault code caused by inverter itself	F1 - MCU fault F2 - Current sensor fault F3 - GFCI sensor fault F4 - Relay fault F12-Dc component out of range F13 - EEPROM fault F14-Master and slave DSP communication failure
Others	It may be caused by external installation environment, PV side and inverter itself. Further Diagnoses needed.	F8 - Temperature is out of range F15 - BUS voltage is too high F16 - BUS voltage is too low F17 - DRM S9 fault F18 - DRM S0 fault